

Description

Depiction

Dimensions in mm

Step 1:

Signal contacts:

Strip insulation from the wire with a length and insert the wire into the rectangular contact chamber.

Power contacts:

Strip insulation from the wire with a length and insert the wire into the contact chamber until insulation is flush with contact. Do not twist the strands of the wire.

Step 2:

Signal contacts:


Tighten screw termination with screwdriver (0.5 x 3.5) with a tightening torque.

Power contacts:

Hold the wire in position and tighten by a hexagonal driver (SW 2) from the mating side with a tightening torque.

Step 3:

Complete connection



I: Stripping length for signal contacts

L: Stripping length for power contacts

